



INSTALLATION INSTRUCTIONS FOR JEEP DROP HITCH BUMPER JB44-RH

HARDWARE SUPPLIED

8	7/16" x 1 1/4" bolts
8	7/16" nuts
8	7/16" lock washers
16	7/16" flat washers
4	1/2" x 1 1/2" bolts
4	1/2" nuts
4	1/2" lock washers
1	bumper
1	hitch bracket

NO DRILLING required  
for installation

Remove the factory bumper. Locate all the 7/16" hardware. Place the hitch bracket in the same location as the factory bumper. Line up the holes in the bracket with the holes in the back of the frame and secure with 7/16" hardware supplied. Position the bumper up to the hitch bracket and secure them together, using the 1/2" hardware supplied.

Be sure to use all hardware supplied and tighten all bolts.

IMPORTANT: To protect your investment, wax this product after installing  
Regular waxing is recommended.

Thank you for buying a Smittybilt product.

