



Installation Instructions

LOWER GUARD REPLACEMENT

Product Number: SGAIR-1, QGAIR-1, SLITE-1, QLITE-1
KGAIR-1, RGAIR-1, KLITE-1, RLITE-1

Application: ALL

I. Overview

Congratulations on your new purchase of a replacement lower guard for your Black Steel bumper.

This Heavy Duty Lower Guard was specifically designed for your application to provide strength and functionality. It was designed in 3-D from digitized data, CNC laser cut, fabricated, and powder coated... all in the U.S.A.

Enjoy the fit and finish of a quality Heavy Duty Lower Guard for your Black Steel or Black Steel Elite Front Bumper from Fab Fours Inc.



Parts List

- Replacement Lower Guard
- 20712-HW OR 50037-HW Fastener Kit (Depends on application)
- Instruction Manual

Tools Required

- Socket Wrench with Extension (Ratcheting wrenches may also be convenient)
- 3/4" Socket
- 3/4" Wrench





Installation Instructions

LOWER GUARD REPLACEMENT

Product Number: SGAIR-1, QGAIR-1, SLITE-1, QLITE-1
KGAIR-1, RGAIR-1, KLITE-1, RLITE-1

Application: ALL

II. Removal of and Replacement of Lower Guard

- A. Using $\frac{3}{4}$ " wrench and socket, remove the stock bolts attaching your lower guard.
- B. Replace the standard bolts with the bolts that have been provided.
- C. Fully tighten and enjoy your new heavy duty lower guard.
- D. ***Maintenance/Care***
 - Periodically check and tighten all fasteners.
 - Stripped, fractured, or bent bolts or nuts need to be replaced.
 - After washing of the vehicle, make sure to fully dry all surfaces.

III. Contact Information

Fab Fours Inc.
1312 Camp Creek Rd
Lancaster, SC 29720

Phone (866)-385-1905
Fax (866)-574-1424
Email Support@fabfours.com



More than expected... Better than expected

