

JK Front Tow Hook Installation Instructions Replaces Part Number: 52060378K

Kit Contents:

2 - Tow Hook

- **1.** Disconnect your negative battery terminal.
- 2. Remove the grille by first removing the 6 screws at the top. Then, tilt the grille forward and remove the parking light plug from the lamp. The grille can now be set aside.
- 3. Remove the upper and lower splash guards and set aside. There are 2 screws holding the upper splash guard and 6 holding the lower splash guard.



- 4. Remove the fog light plugs from the lamp (if equipped) and remove all wiring from the bumper prior to removal.
- **5.** Remove the front bumper beam and cover as an assembly by removing the 8 nuts from the backside of the beam. Set hardware aside for future use.
- **6.** Remove the front bumper cover from the beam by removing the 4 bolts (2 on each side) from each side.
- 7. If your bumper cover does not have holes in it to accommodate the tow hooks, they need to be drilled. Start by drilling a 1/8" hole on the 4 corners of the indentations of cover. Using a small body saw or something similar cut the square hole out by connecting the holes. Repeat on the other side.
- **8.** Remove the 4 stock stud plates from the bumper beam and discard them.
- **9.** Slide the tow hooks into the bumper cover with the studs facing the rear of the vehicle. Continue by installing the bumper beam on the backside of the cover. Affix the bumper beam to the cover using the original hardware.
- **10.** Install the bumper assembly onto the vehicle using the original hardware. Torque hardware to 85 ft. lbs. Reconnect fog light plugs (if equipped) and affix all wiring to the bumper.
- 11. Install the upper and lower splash guards followed by the grille.
- **12.** Reconnect your negative battery terminal.