

**List of Contents:**

**Qty:**

- 1 Pc. Rear Wheel Well Inner Liner, Passenger Side
- 1 Pc. Rear Wheel Well Inner Liner, Driver Side



- 1 Pc. Installation Kit
  - \* 2 pc. Plastic Push Pin (Large)
  - \* 4 pc. Plastic Push Pin (Small)
  - \* Installation Instructions.



**Required Tools:**

- \*Ratchet with socket of 10 mm
- \*Utility Knife
- \*Electric drill with 1/4" drill bit
- \*Easy Removal Tool



**Preparations:**

- \*Remove the tires for easy installation
- \*Clean the interior panels of the rear Wheel house

**Technical Support phone line:**

**1-800-222-7023**

**Instructions:**

Installation time estimated: 30 min.

**1. PLEASE READ INSTRUCTIONS CAREFULLY BEFORE STARTING THE INSTALLATION.**

**NOTE:** One person installation.

**Starting on the Driver's Side:**

**2.** Locate the top support bracket and remove the interior bolt using the wrench with 10mm socket (see fig A & B).

"keep the bolt in a safe place"

**3.** Using an electric drill with 1/4" drill bit, drill a hole in center of the marked circle, located on the bottom corner of the sheet metal. (See fig. C).

**4.** With the help of an easy removal tool, remove the lower plastic push pin, and discard. (See fig. D).

**5.** Trim the excess length of the lower plastic push pin, leaving approx. 1/8" of the length on the rear side. (see fig. E).

**6.** Using an electric drill with 1/4" drill bit, drill a hole in center of the dimple marked as (04), located on the rear face of the plastic protector. (See fig. F).

