



INSTALLATION INSTRUCTIONS

2021+ FORD F-150 AND RAPTOR A-PILLAR



PRODUCTS INCLUDE:

- MOUNT KIT #46736

RECOMMENDED TOOLS:

- 13mm socket
- 10mm socket

IMPORTANT

THANK YOU FOR PURCHASING RIGID INDUSTRIES' PRODUCTS FOR YOUR VEHICLE.

Please read through all of these instructions and tips before proceeding with the installation.

We do our best to provide a simple installation process for all applications however a professional installation is always recommended.

Always disconnect any power sources connected to your vehicle before servicing fuses or electrical systems.

STEP: 1

Open the vehicles hood and locate the hood hinges.
Remove the two factory bolts shown using a 13mm socket.



STEP: 2

Install bracket brace onto main bracket using the supplied M6 bold and M6 U-Nut.



STEP: 3

Slide the bracket into place and re-install the bolts removed in step 1. Do not fully tighten.



STEP: 4

Verify bracket position, making sure that it is not contacting the hood while it is fully open as shown below.



STEP: 5

Tighten hinge bolts using a 13mm socket. Tighten all hardware and repeats steps 1-4 on the opposite side of the vehicle.



Your installation is now complete.
Welcome to the Rigid Nation!

WARRANTY INFORMATION

For warranty information, visit www.rigidindustries.com/about/warranty 779 N Colorado St, Gilbert, AZ 85233 · 855-760-5337
www.rigidindustries.com

RIGID, D-Series, 360-Series and Rigid Industries are registered and/or common law marks owned by JST Performance, LLC, a Delaware limited liability company d/b/a Rigid Industries.

11-14213-A