



aFe Power Engine Cover

PN: 54-32418

Important!

Please read all instruction steps before you begin installation.

Make	Model	Year	Engine
Dodge/RAM	RAM 2500/3500	2013-2016	L6-6.7L (td)

Tools Required: 1) 3/8 End Wrench or Socket.

Step 1. Remove edge trim from housing.

Step 2. Slide the 3 panel nuts over the housing edge at the punched hole locations. The threaded portion should face the filter.

Step 3. Install the cover using the supplied hex screws. Do NOT over tighten.

Your install is now complete!



advanced FLOW engineering

252 Granite Street, Corona, CA 92879

Support: 951-493-7100

www.aFePower.com