



Silver Bullet

Throttle Body Spacer

PN 46-33020

Important!

Please verify the parts list and read all instruction steps before you begin installation.

Make	Model	Year	Engine
Ford	Mustang GT	2011-2023	V8-5.0L
Ford	F-250 / F-350	2020-2023	V8-7.3L

- Step 1.** Remove the engine cover to gain access to the throttle body.
- Step 2.** Using a 7mm socket, loosen the two clamps on the intake tube. Disconnect all three SAE fittings from the intake tube. Using a pair of pliers, remove the spring clamp from the large 1" rubber hose and then disconnect the hose from the intake tube.
- Step 3.** Using an 8mm socket, remove the four bolts securing the throttle body. (These bolts will not be reused for this installation, but you should save in case throttle body spacer is ever to be removed.)
- Step 4.** Install the new **Silver Bullet** Throttle Body Spacer in between the intake manifold and the throttle body. Ensure the engraved side of the spacer that is marked with the part number, "TOP" and "AIR IN" is positioned properly and that it is facing the throttle body. Install the supplied gasket in-between the throttle body and the throttle body spacer. Use the supplied hardware to secure the throttle body, gasket and spacer to the intake manifold by using a 10mm socket. Place the flat washer, lock washer, and then the M6 bolt (in that order) into the four mounting locations.
- Step 5.** Reinstall the intake tube. Connect all three SAE connectors. Reattach the 1" rubber hose & spring clamp and tighten both hose clamps (using 7mm socket) to secure the tube.
- Step 6.** Reinstall the engine cover and press down firmly on the mounting points to verify proper installation.

NOTE: This part has been exempt by the California Air Resources Board (C.A.R.B.) and issued an Executive Order (E.O.). If part does not come with C.A.R.B. E.O. sticker already placed on device, it is necessary to place the sticker on or near the device on a smooth, clean surface. The C.A.R.B. E.O. sticker is required to pass the smog test inspections in the state of California.

Your install is now complete! Make sure to retighten all bolts and clamps after 100 miles of driving.



Step 1



Step 2



Step 3



Step 4-5



Step 6

Parts List

- 1 **Silver Bullet** Spacer
- 1 Gasket
- 4 M6 flat washers
- 4 M6 lock washers
- 4 M6 x 1 x 70mm bolts

Tools Needed List:

7mm Socket, 8mm Socket, 10mm Socket, Socket Driver/Ratchet, and Pliers.

advanced FLOW engineering, Inc.

Corona, CA
www.aFepower.com