



INSTALLATION INSTRUCTIONS

MAKE: Nissan

MODEL: Xterra

YEAR: 05-15

ENGINE: V6-4.0L

ALSO FITS: 05-18 Nissan Frontier V6-4.0L

05-12 Nissan Pathfinder V6-4.0L

09-12 Suzuki Equator V6-4.0L

Rear, Cat Replacement

47-46103

47-46104



Parts Included:

- P/N: 05-144177 S/A Tube, Front Pipe (Driver Side) (x1)
- P/N: 05-144178 S/A Tube, Front Pipe (Passenger Side) (x1)

Hardware Included:

- P/N: 03-50401 Bolts, 10mm (x2)
- P/N: 03-50400 Nuts, 10mm (x2)
- P/N: 05-46216 Gasket (x2)
- P/N: 06-00140 Warranty Card (x1)

CAUTION: Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Exhaust systems reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. aFe recommends professional installation on our products.

Step 1: (Read Instructions prior to installation). Secure vehicle on jack stands (refer to your manual for specified jack stand positions).

Step 2: Disconnect the negative terminal from the battery.

Step 3: Remove O2 sensor. Check it for damage, replace it necessary.

Step 4: Unbolt catalytic converter from both ends.

Step 5: Remove catalytic converter.

Step 6: Install aFe Power catalytic converter using supplied (x2) gaskets and hardware.

Step 7: Connect O2 sensor to aFe Power catalytic converter.

Step 8: Connect negative battery terminal.

Step 9: Double check your work then start vehicle to check for any leaks.

Step 10: Remove vehicle from jack stands.

Step 11: Congratulations, your install is now complete!(Check all bolts after 50-100 miles of install and tighten any necessary bolts.)