



INSTALLATION INSTRUCTIONS

MAKE: Dodge
MODEL: 2500/3500
YEAR: 2003-2007
ENGINE: L6-5.9L (td)

**Intercooler
46-20019**



Parts Included:

- Intercooler Tube (x1)
- Couplings (x2)
- Clamps (x4)

Tools Needed:

- 11mm Deep Socket
- Ratchet

CAUTION: Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Engine bays reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. aFe recommends professional installation on our products.

1. Park vehicle on level ground and apply parking brake, use wheel chokes if necessary.
2. Loosen both clamps at each end of the intercooler tube and remove tube.
3. Remove couplings and clamps from vehicle, replace with aFe couplings and clamps.
4. Install aFe intercooler tube and tighten all clamps back down.
5. Install is complete.
6. Enjoy and thank you for choosing aFe Power!