



## INSTALLATION INSTRUCTIONS

**MAKE:** Dodge  
**MODEL:** Diesel Trucks  
**YEAR:** 2007.5-2009  
**ENGINE:** L6-5.9L (td)

## Intercooler Tube 46-20039



### Parts Included:

- Intercooler Tube (x1)
- Coupling (x2)
- Clamp (x4)
- Plugs (x2)

### Tools Needed:

- 11mm Socket
- Extension
- Ratchet
- 6mm Allen Wrench

**CAUTION:** Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Engine bays may reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. aFe Power recommends professional installation on our products.

1. Park vehicle on level ground and engage parking brake.
2. Disconnect batteries.
3. Loosen the clamps on each end of the intercooler tube that connect the couplings to the intake manifold and the intercooler using an 11mm socket.
4. Remove the stock intercooler tube from the vehicle.
5. Install one (1) clamp and coupling onto the intercooler.
6. Install the aFe intercooler tube into the vehicle with the last smaller clamp.
7. Install the final coupling and clamps into the vehicle.
8. Once everything is installed into the vehicle, slide the couplings and clamps into place and make sure the tube is not touching any metal surfaces, then tighten them using an 11mm socket.
9. Reconnect batteries.
10. Installation is now complete.

Enjoy and thank you for choosing aFe Power!