



INSTALLATION INSTRUCTIONS

MAKE: DODGE
MODEL: RAM 2500/3500
YEAR: 2013-2016
ENGINE: L6-6.7L (td) CUMMINS

**Cast Intercooler
46-20131**

aFe recommends professional installation on our products



Parts Included:

- Intercooler (x1)

Tools Needed:

- 10mm, 13mm, 21mm Socket
- 7/16" Deep Socket
- 3/8" Driver Ratchet
- 3/8" Driver Extension
- Panel Popper
- Pliers
- Pick
- 13mm Wrench

CAUTION: Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Engine bays reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. aFe recommends professional installation on our products.

Step 1. Disconnect batteries in vehicle before installation.

Step 2. Remove air box, intake tube, intercooler tubes, clamps.

Step 3. Remove crash bars below intercooler if present.

Step 4. Remove lower bumper valence.

NOTE: Support intercooler while unbolting intercooler brackets.

Step 5. Unbolt intercooler brackets and remove intercooler from vehicle.

Step 6. Install factory rubber isolators, brackets, and fan shroud on to aFe intercooler.

Step 7. Install aFe Intercooler.

Step 8. Reinstall lower bumper valence.

Step 9. Reinstall crash bars (if removed).

Step 10. Reinstall intercooler tubes, clamps, intake tube, and air box.

Step 11. Connect batteries.

Step 12. Your installation is now complete, Enjoy!

Note: legal in California only for racing vehicles which may never be used upon a highway.
