




## INSTALLATION INSTRUCTIONS

**MAKE:** Ford  
**MODEL:** Mustang GT  
**YEAR:** 2015-2017  
**ENGINE:** V8-5.0L

**Axle-Back Exhaust System**  
49-43105-B (Black Tips)  
49-43105-C (Carbon Fiber Tips)  
49-43105-P (Polished Tips)



**Caution:** aFe recommends professional installation on our products. Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Exhaust systems reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation.

**Step 1: (Read instructions prior to installation)** Secure vehicle on jack stands (refer to your manual for specified jack stand positions).

**Step 2:** Remove stock exhaust. Be cautious not to damage rubber isolators when removing from vehicle.

**Step 3:** From tangent line, measure and mark a line 3" away going outward for both left and right side (refer to Figure A). Cut factory under-axle pipe where marked and remove rear mufflers.

**Step 4:** Clean the under-axle pipes and de-burr the edges.

**Step 5:** Install factory under-axle pipe (without OEM mufflers).

**Step 6:** Install right aFe power muffer using supplied 2-1/2" clamp. Do not tighten at the moment.

**Step 7:** Install left aFe power muffer using supplied 2-1/2" clamp. Do not tighten at the moment.

**Step 8:** Check your exhaust system for proper clearance. Once aligned and satisfied with fitment, you may now tighten complete exhaust system.

**Step 9:** Start vehicle and check for any leaks.

**Step 10:** Remove vehicle off jack stands.

**Step 11:** Your installation is now complete. It is recommended to re-tighten all exhaust components after 50-100 miles.

