

INSTALLATION FOR CUMMINS BYPASS CABLE (#40471)

1. Working from the footwell of the driver seat, locate green terminal block as pictured. This is typically under the dash towards the firewall and can be accessed without removing any dash panels.
2. Locate an open slot in the green terminal block
3. Plug the rectangular connector at the end of the cable into the open slot selected
4. Run length of cable as desired. Remember this cable is only required for vehicle programming.
5. Plug mini USB connector at other end of cable into open slot of the HDMI to OBD2 cable near the HDMI end.
6. You may now use your tuner to program a 2018+ Cummins!

