



advanced FLOW engineering

Instruction Manual P/N: 52-10003C

Rapid Induction Cold Air Intake System Cover

Ford Edge ST 2019-2023 V6-2.7L(tt)
Ford Edge Sport 2015-2018 V6-2.7L(tt)



Qty.	Part Description
1	Rapid Induction Cover
1	Trim Seal, 9.5" length
1	Trim Seal, 9.375" length

- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components, call customer support at 951-493-7100.
- Ensure you have all necessary tools before proceeding.
- Ensure that your vehicle is cooled off before proceeding.
- Retain factory parts for future use.

1. Remove the trim seal from your aFe POWER Cold Air Intake System.
2. Install the two provided strips of trim seal along the long side of the housing. The longer strip goes on the side where the intake tube is mounted.
3. Install your new cover, ensuring the locking tabs are on the inside of the sheet metal housing and the longer edges sit on the outside.

NOTE: Check all screws, clamps, and connectors are secure after 100-200 miles