

# *aFe Control*

## *Rear Suspension Strut Brace*

### *20-23 Chevrolet Corvette C8 V8-6.2L*

**Product Number:** 450-401016-H

**Install Time:** 15 Min. (Rear Strut Brace),



<b>Full Kit Contents</b>	<b>Front &amp; Rear Sway Bar Set</b>	<b>Qty.</b>
00P-0P2674-A	Strut Brace - Corvette C8 Left	1
00P-0P2675-A	Strut Brace - Corvette C8 Right	1

#### **Recommended Tools:**

- Sockets
- Panel Popper
- Socket Wrench
- Torque Wrench

**Installation:**

1. Remove the wire harness retainer securing the wire harness at the rear of the driver side strut brace.
2. Remove the 8 Torx bolts securing the driver side strut brace to the chassis.
3. Remove the driver side strut brace.
4. Install the aFe Control strut brace with the OE hardware.
5. Tighten Hardware to 23 Nm (17 ft-lb)
6. Install the wire harness retainer into the bottom of the aFe Control strut brace.
7. Remove the wire harness retainer securing the wire harness at the rear of the passenger side strut brace.
8. Unclip the evaporative emission canister purge pipe and hose.
9. Remove the 8 Torx bolts securing the passenger side strut brace to the chassis.
10. Remove the passenger side strut brace.
11. Install the aFe Control strut brace with the OE hardware.
12. Tighten Hardware to 23 Nm (17 ft-lb)
13. Install the wire harness retainer into the bottom of the aFe Control strut brace.
14. Clip the evaporative emission canister purge pipe and hose.

