



EVO-1113B

EVO MFG JK Front Shock Relocation Kit



- 1 EVO-11092B PASS LWR B/O C/O MOUNT
- 1 EVO-11092DB DRVR LWR B/O C/O MOUNT
- 1 EVO-770046 HARDWARE PACK

1. Remove lower shock bolt and remove shock out of factory bracket.

2. Turn the steering wheel to provide access to drill on the side of the factory coil spring perch.

3. Enlarge the existing hole on the side of the factory coil spring perch to 11/32" .

4. Enlarge reward hole on the underside of factory shock mount to 7/16" .



5. **Loosely** install the EVO MFG Front shock relocation bracket (**DO NOT TIGHTEN at this point**). 2 Bolts on the underside of the factory shock mount with 3/8" hardware and side bolt with 5/16" hardware.

6. Install shock into EVO relocation bracket using the provided 1/2" hardware and tighten shock with all other bolts loose.

7. Tighten all other bracket mounting hardware.

8. Repeat these steps for other side of the vehicle.

