



EVO-1077

EVO 3" Front Bumpstop Spacer Kit



	QTY	PART#	DESCRIPTION
<input type="checkbox"/>	2	EVO-20005	Front Bumpstop Spacer 3"
<input type="checkbox"/>	2	EVO-900333	Thread-Cutting Screw for Metal&Plastic

1. Drill 5/16" hole in center of spring perch.
2. Using socket with extension, enter bolt into bump stop.
3. Place over hole drilled in spring perch.
4. Tighten bolt applying downward pressure keeping bolt as straight as possible to allow self tapping screw to thread.
5. Tighten snug, do not over tighten.