



## EVO-1125B

### A Pillar Light Mount Pair, JK



Part#	Description	Qty
EVO-12064B	Passenger A Pillar Bracket	1
EVO-12065B	Driver A Pillar Bracket	1
EVO-900348	Nylon Flat Washer 5/16"	4

1. Remove the two factory T30 Torx bolts from the A Pillar.
2. Place one washer in each of the four A Pillar indentions.
3. Place the EVO A Pillar Light Mount up to the vehicle A Pillar with the Laser Cut O facing the outer side of the vehicle.
4. Reinstall the Factory T30 Torx bolts and tighten snug ( **DO NOT OVERTIGHTEN** ).
5. Repeat steps on opposite side of vehicle.