



EVO-1165AL(B)

EVO B-Pillar Rockskins



Bill of Materials

Part number	EVO-1165AL(B) Description	Quantity
EVO-12175AL	EVO B-Pillar Rockskin Driver	1
EVO-12176AL	EVO B-Pillar Rockskin Passenger	1
EVO- 770060	B-Pillar Rockskin Hardware Pack	1

Note: This product is intended to fit 4 door JK Wranglers only

Note: This kit requires drilling into the body of your vehicle. Make sure the B-Pillar Rockskin follows the doors and bodylines of your vehicle to your satisfaction before proceeding with install.

You only get one shot at correct install. Before drilling, make sure you are satisfied.

Nutsert tool/Threaded insert tool should be used for installation and can be found online at such places as Amazon, Harbor Freight, and many other tool supply company's web sites. Thread size required is ¼-20

1. Tape off the B-Pillars Prior to marking and drilling.
2. Only after taping the body off to avoid scratches in the paint, hold the B-Pillar Rockskins against the body and position them to match the body lines and the outline of the doors. Mark the 4 holes to be drilled on each side. Be sure the Rockskins are tight to the body do not move while marking (this may be easier to do with 2 people).



3. Only if you are satisfied with the position of the B Pillar Rockskins, center punch and then pilot drill all the holes into the body sheet metal. You only want to drill through the surface layer of sheet metal, and no deeper.

Note: When Drilling Body Sheet Metal, go very slow and use light pressure, the drill may have a tendency to bite in. It is recommended to start small and step up the size of the drill incrementally



4. Use a 3/8" to 25/64" drill bit to open the holes up. Drill sizes can vary, so verify your fitment with the threaded inserts (At this point only check the fit of the threaded inserts, do not install them)
5. Use a countersink (or larger drill bit) to remove the flared edge left around each hole on body.
6. Use threaded insert tool to install threaded inserts/rivet nuts in all holes drilled into the body.



Note: The B-Pillar Rockskins come with 2 sets of hardware to match armor on your vehicle. If your vehicle has flat head hardware (EVO MFG Rockskins) install The B-Pillar Rockskins with countersunk holes facing out to fit the flat head hardware. If your vehicle has button head hardware (EVO MFG Boatside Bombers) install the B-Pillar Rockskins with the counter sunk holes against the body (flat side out).

7. Using a 5/32" Allen wrench to thread the supplied hardware on. Once all screws are threaded, fully tighten them.

