



Crown Automotive Sales Co., Inc.

Fuel Module Float Arm Assembly Instructions
Replaces P/N: 5183202AA




Figure 1




Figure 2

This fuel module ships with the arm detached from the module. To assemble float arm onto the fuel module insert the float arm into the hole (see Figure 1) and rotate the arm down so it engages the 2 clips on the bracket (see Figure 2). Ensure that it has a full range of motion and the float arm does not contact the body of the fuel module.