



INSTALLATION MANUAL
POLARIS RZR FRONT BUMPER
PRODUCT NUMBER: SXFB-1150
APPLICATION: 14+ POLARIS RZR 1000 XP, & S



IMPORTANT SAFETY GUIDE | Your safety and the safety of others is very important.

In order to help you make informed decisions about safety, we have provided the following warnings, safety precautions, installation instructions, and other important information to alert you to potential hazards that could hurt you or others.

Please do a job safety analysis before each task to identify potential hazards for your situation and remove/protect against them. Use own good judgment and take your time.

Check packaged materials immediately upon arrival to ensure that all listed parts are included and undamaged.

Read and understand all warnings, safety precautions, and instructions before installing this product.

SENSORS FIELD OF VIEW MAY BE ALTERED WITH USE OF THE REPLACEMENT BUMPER.

WARNINGS

- Failure to observe the following warnings and instructions provided in this manual could lead to severe injury and/or death.
- For professional installation only. Careless installation and/or operation can result in serious injury, death, and/or equipment damage. All liability for installation and use rests with the user or consumer.
- Fab Fours, Inc. only approves installing this product according to these written instructions with the hardware provided. Failure to install according to these instructions will invalidate the warranty. This includes, but is not limited to, using alternative installation methods, hardware, or materials.
- This product is for off road use only.

SAFETY PRECAUTIONS

- Always remove jewelry and wear eye protection.
- Always use extreme caution when jacking up a vehicle for work. Set emergency brake and use tire blocks. Locate and use the vehicle manufacturers designated lifting points. Use jack stands.
- Always use appropriate and adequate care in lifting components into place.
- Always ensure components will remain secure during installation and operation.
- Always wear safety glasses when installing this kit. A drilling operation will cause flying metal chips. Flying chips can cause serious eye injury.
- Always use extreme caution when drilling a vehicle. Always disconnect power before welding. Thoroughly inspect the area to be drilled (on both sides of material when possible) prior to drilling, and relocate any objects that may be damaged.
- Always use extreme caution when welding a vehicle. Thoroughly inspect the area to be welded (on both sides of material when possible) prior to welding, and relocate any objects that may be a fire hazard. When welding in a cab, make sure the interior surfaces are covered (e.g., welding blanket) and a fire extinguisher is at hand.
- Always use extreme caution when cutting and trimming during fitting.
- Always tighten all nuts and bolts securely per installation instructions.
- Always route electrical cables carefully. Avoid moving parts, components that become hot, and rough or sharp edges.
- Always insulate and protect all exposed wiring and electrical terminals.
- Perform regular inspections and maintenance on mounts and hardware.

TABLE OF CONTENTS

- 2 SAFETY / DISCLAIMER
- 3 TABLE OF CONTENTS
- 4 A MESSAGE FROM THE OWNER
- 5 GETTING STARTED
- 6 PROVIDED MATERIAL
- 7 DISASSEMBLY
- 8 INSTALL
- 10 CONTACT

A MESSAGE FROM THE OWNER



Fab Fours' was born out of a passion for customizing vehicles and a love of the outdoors. Our engineering team uses the latest 3D design software to turn new product ideas into reality. In our factory, designs come to life with the combination of cutting edge technology for metal cutting and forming and an American workforce that puts its' heart and pride into every product.

From design and manufacturing, to quality and delivery, Fab Fours' mission is to be the market leader for steel truck and jeep accessories. We make sure a quality product is delivered on time, more than expected, better than expected to our customers.

Enjoy your new Fab Fours product. Welcome to the family!

Ereg Higgs

FOUNDER, FAB FOURS

GETTING STARTED

Before you begin the installation process of your new Fab Fours product, we suggest laying out all materials and parts on a pad or protective surface.

Failure to fully account for all components before beginning installation may leave vehicle immobile until part is acquired. Refer to the next pages as an inventory check.



PROVIDED MATERIALS



22073

HARDWARE KIT | 50212

FAB FOURS IDENTIFICATION	COMPONENT DESCRIPTION	QTY
50212-HW	3/8"-16 x 1", Yellow zinc, GR 8, Carriage bolt	4
50212-HW	3/8" x 1")D, Yellow zinc, GR 8, Flat washer	6
50212-HW	3/8" Yellow zinc, GR 8, Nylock nut	4
50212-HW	3/8" Yellow zinc, GR 8, Lock washer	2
50212-HW	3/8"-16 x 1", Yellow zinc, GR 8, Hex head bolt	2

TOOLS REQUIRED

- 9/16" Open end wrench
- 9/16" socket wrench
- 10mm Socket wrench
- 1/2" Drill bit
- Drill

ASSISTANCE

We recommend two people perform the installation as items are heavy and may need to be held in place while installing.

ORGANIZATION

Disassemble the vehicle where you can catalog and store everything. We suggest labeling and bagging all the OEM bolts when removing from the vehicle. Failure to keep track of parts could lead to an inability to properly reinstall components.

DISASSEMBLY

NOTE: 2014-2018 Year Models

1. Using a 10mm socket wrench, remove the two (2) OEM screws attaching the winch cover plate. (Figure 1)



Figure 1

2. Remove the grille insert from the vehicle by depressing on the two (2) tabs at the top and pulling outward. (Figure 2)



Figure 2

3. Remove the grille insert from the vehicle by depressing the two (2) tabs at the top of the insert and pulling outward. (Figure 3)



Figure 3

INSTALLATION

4. If installing a winch, do so now per the winch manufactures instructions.




Figure 4

5. If installing a lightbar do so now using the light manufactures provided hardware. (Figure 4)



6. Using a drill with a 1/2" bit, enlarge the two (2) inner holes in the upper mounting flange. (Figure 5)




Figure 5

7. Using the four (4) provided 3/8" carriage bolts, flat washers, and nylock nuts (50212-HW) install the bumper (22073) to frame at the upper mounting flange. (Figure 6)

Note: It may be necessary to remove the four (4) bolts that mount the front differential to the bottom of the frame to push the differential back to help gain access for the process in step 6. (Figure 7)




Figure 6

8. Using the two (2) provided 3/8" hex head bolts, flat washers, and lock washers (50212-HW) install the bumper (22073) to the two holes at the lowest portion of the frame. Thread the bolts in from the backside of the frame. (Figure 8)

9. Using a 9/16" socket wrench, tighten the hardware installed in step 7.

10. Using a 9/16" open end wrench, tighten the hardware installed in step 6.

11. Reinstall the grille insert removed in either steps 2 or 3.

Maintenance/Care

- Periodically check and tighten all fasteners.
- Stripped, fractured, or bent bolts or nuts need to be replaced




Figure 7




Figure 8

CONTACT INFORMATION

**FAB FOURS INC.
2213 INDUSTRIAL PARK ROAD
LANCASTER, SC 29720**

PHONE: (866) 385-1905

FAX: 866-574-1423

EMAIL: SUPPORT@FABFOURS.COM

WWW.FABFOURS.COM



**“IF YOU’RE LOOKING FOR MORE OF THE SAME,
THEN YOU’VE COME TO THE WRONG PLACE.”**

- GREG HIGGS

