



INSTALLATION INSTRUCTIONS

MAKE: DODGE
MODEL: RAM 2500/3500
YEAR: 1994-2002
ENGINE: L6-5.9L (td) CUMMINS

Intercooler and Tubes 46-20062



Parts Included:

- Intercooler (1)
- Intercooler Tubes (2)
- Couplers (4)
- Clamps (8)
- Bolts (8)
- Washers (12)
- Nuts (4)
- Plugs (4)

Tools Needed:

- 10mm Socket & Wrench
- 10mm Socket & Wrench
- 18mm Deep Socket & Wrench
- 7/16" Deep Socket
- 3/8" Driver Ratchet
- 3/8" Driver Extension
- Flathead Screwdriver
- Pliers

CAUTION: Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Engine bays reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. aFe recommends professional installation on our products.

Note: Inner fender well MAY need to be bent out of the way for clearance for the intercooler tubes on some vehicles.

1. Disconnect batteries in vehicle before installation.
2. Remove air box, intake tube, intercooler tubes, clamps and couplings.
3. Remove hood latch, upper core support and front bumper.
4. Remove bolts securing fan shroud and intercooler.
5. Lift radiator (1 side at a time) to slide stock Intercooler out for removal and remove intercooler.
6. Install OE rubber grommets off of OE Intercooler onto aFe Intercooler.
7. Install aFe Intercooler.
8. Install aFe couplers, clamps and tubes.
9. Tighten clamps until spring is completely compressed.
10. Install bolts removed in step 4.
11. Install Parts removed in steps 2 and 3.
12. Connect everything disconnected in step 1.
13. Your installation is now complete, Enjoy!

Note: legal in California only for racing vehicles which may never be used upon a highway.