



advanced FLOW engineering

Instruction Manual P/N: 77-46601

Make: **Honda**
Make: **Honda**
Make: **Honda**
Make: **Honda**

Model: **Civic**
Model: **Civic Si**
Model: **Accord**
Model: **Accord**

Year: **2016-2021**
Year: **2017-2020**
Year: **2018-2021**
Year: **2018-2021**

Engine: **L4-1.5L Turbo**
Engine: **L4-1.5L Turbo**
Engine: **L4-1.5L Turbo**
Engine: **L4-2.0L Turbo**



- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components, call customer support at 951-493-7185.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.
- Disconnect the negative battery terminal before proceeding.
- Retain factory parts for future use.

Label	Qty.	Description	Part Number
A	1	Module	R77-46601
B	1	LED Switch	05-70029
C	2	Velcro (2" Inches)	05-01244
D	4	Cable Ties	05-60167

Warranty Information available at: <https://afepower.com/contact#warranty>

Note: Legal in California for use on race vehicles only. The use of this device on vehicles used on public streets or highways is strictly prohibited in California and others states that have adopted California emission regulations.






SLEEP MODE

Figure A

Refer to Figure A for Step 1.


Step 1: Before installing your aFe module, you will have to place your vehicles ECU in sleep mode. In order to do this you will need to do the following:

- If the engine is cold, open the hood, close the doors lock the car and wait 30 seconds.
- If the engine is warm, open the hood, close the doors lock the car and wait 20 minutes.
- If the engine is warm and you can't wait 20 minutes, disconnect the battery.



Refer to Figure B for Step 2.

Step 2: Locate the MAP and TMAP sensors. The MAP sensor is located on top of the intake manifold. TMAP is located on the charge pipe between the battery and the engine.

**Figure B****Refer to Figure B for Steps 3-4.**

Step 3: Locate and disconnect the MAP sensor, on top of the intake manifold.

Step 4: Locate the MAP sensor jumper harness on the aFe module. This is the longer harness. Plug the female connector of the module into the stock MAP sensor, then take the male connector of the module and connect to the female connector of the engine harness.



Note: Make sure connections are fully engaged. Usually, connectors make a snapping sound when fully engaged.



Figure C

Refer to Figures C for Steps 5-6.

Step 5: Disconnect the TMAP sensor.

Step 6: Locate the TMAP sensor jumper harness on the aFe module. This is the shorter harness. Plug the female connector of the module into the stock TMAP sensor, then the male connector of the module female connector of the engine harness.



Figure D

Refer to Figure D for Steps 7-8.

Step 7: Carefully route the switch cable behind the center console.

Step 8: Mount the Switch on an open, flat surface.

**Figure E****Refer to Figure E for Step 9.**

Step 9: Route the switch cable through firewall and into the engine bay. Plug the end of the cable to the module.



Figure F

Refer to Figure F for Step 10.

Step 10: Mount the module in a safe location, using the supplied Velcro strip. Then, secure the wires and module away from any extreme heat and moving parts, with the provided ties.



Note: Make sure connections are fully engaged. Usually, connectors make a snapping sound when fully engaged.



Figure G

Refer to Figure G for Step 11.

Step 11: When turning on the vehicle, each LED will flash. It will stop at its last setting.

The LED on the switch represents the different level of power.

- Green LED: Stock
- Yellow LED: Sport
- Orange LED: Sport+
- Red LED: Race

Use the grey button to select the desired setting. Power adjustments can be done at any moment.

Thank you for choosing aFe POWER!



advanced FLOW engineering, inc.
252 Granite Street Corona, CA 92879
TEL: 951.493.7100 TECH: 951.493.7185
E-Mail: Tech@aFepower.com