

advanced FLOW engineering

Dynamic Air Scoop D.A.S.

Instruction Manual P/N: 56-70016S

Make: **Acura**

Model: **TLX**

Year: **2015-2020**

Engine: **V6-3.5L**



- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components, call customer support at 951-493-7185.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.
- Retain factory parts for future use.


Label	Qty.	Description	Part Number
A	1	Scoop, Rotomold: 56-70016	05-5670016B3
B	1	Mount, Rubber	05-50534

Installation will require the following tools:

Small flat-head screwdriver

Warranty Information available at: <https://afepower.com/contact#warranty>

Emissions Disclaimer: This product is not currently CARB exempt and is not available for purchase in California or for use on any vehicle registered with the California Department of Motor Vehicles



**Figure A****Refer to Figure A for Steps 1**

Step 1: Remove the two factory push clips from the factory scoop ① do not discard push clips.

Step 2: Pull the factory scoop out of the vehicle.



Figure B

Refer to Figure B for Step 3

Step 3: Insert the supplied grommet (2) onto the Takeda air scoop.



Figure C

Refer to Figure C for Step 4-5

Step 4: Insert the Takeda scoop first into the factory silicone coupling then into the Takeda airbox.

Step 5: Secure the scoop with the previously removed factory push clips from step 1.

Installation is now complete. Thank you for choosing Takeda!



PAGE LEFT BLANK INTENTIONALLY



advanced FLOW engineering, inc.

252 Granite Street Corona, CA 92879

<https://afepower.com/contact>